

Installing Wall Clips or “U” Clamps For Fixed Panels

U Clamps are used to achieve structural strength and add symmetry to your shower enclosure. A 3/16” clearance gap has been allowed for proper installation of the clamp.

Marking Clamp Position For Installation

1. The easiest way to ensure that the panel will be positioned in the correct place is to determine the center-line of your glass on the curb, wall or ceiling.
2. Attach the U clamps to the glass and align the glass panel along the center line.
3. Mark the positioning of the clamps with a pencil and ensure that the panels and door will all fit as per plan.
4. Remove the clamps from the glass panels, mark the locations where you plan to drill the holes. Using a 1/4” masonry bit or glass bit, drill your holes. Ideally you will be going into a wood stud or backing behind the tile. If not use a plastic anchor with a little silicone to hold it securely.
5. Mount all the required clamps. Insert the clear gasket inside the face of the clamp. Mount the panel on the clear vinyl setting blocks and position the glass to its correct position. Manually screw the outer plate to the fixed clamp and glass.
6. Apply tape to the sides of the glass and the wall or curb. Apply silicone sealant inside and out.